

GEAR CHECKS PROCEDURES

- Check equipment repack documentation: Reserve repack valid 1 year
- Check Valid and maintained AAD documents

Please note that while Skydive Spain will try and facilitate as much as we can, it is any visitor's responsibility to prove that their own documents and in date, in a language that can be read by the staff.

Equipment inspection

Please make sure your equipment is suitable for the type of skydiving you intend to do.

Please note to be cleared as **freely friendly**, Skydive Spain require non-velcro riser covers, exposed main bridle cover, good condition BOC bungee.

Skydive Spain reserves the right to stop anyone jumping equipment that we feel is not appropriate for their experience, currency, or the intended jump. This also applies to main and reserve canopy size.

Guidelines for main canopies

- Semi Elliptical and Elliptical canopies between B License up to 200 jumps check the Sizing Chart “Minimum Canopy Size **Recommendations**”
 - Higher performance elliptical minimum 500 jumps (Katana, Stiletto, etc)
 - Cross-braced minimum 750 jumps (VELOCITY, JVX, JFX, ETC)
 - High Performance Cross-braced minimum 1500 jumps (Leia, Valkyrie, Etc.)
- IN CASE OF DOUBT ABOUT HIGH PERFORMANCE CANOPY ASK SO OR CI**

MINIMUM CANOPY SIZE RECOMMENDATIONS

		Exit Weight (kg)															
		45	50	55	59	64	68	73	77	82	86	91	95	100	105	109	114
JUMPS	0-25	190	190	190	190	190	190	190	200	200	220	220	220	220	240	260	280
	26-50	170	170	170	170	170	190	190	190	190	190	190	200	200	220	240	260
	51-100	170	170	170	170	170	170	170	170	170	190	190	190	200	200	220	240
	101-200	150	150	150	170	170	170	170	170	170	170	170	170	190	200	200	220
	201-300	150	150	150	150	150	150	150	150	170	170	170	170	190	190	190	200
	301-400	135	135	135	150	150	150	150	150	150	150	170	170	170	190	190	190
	401-500	135	135	135	135	135	135	135	135	150	150	150	170	170	170	190	190
	501-750	120	120	120	135	135	135	135	135	135	135	150	150	170	170	170	170
	750-1000	107	120	120	120	135	135	135	135	135	135	135	150	150	170	170	170
	>1000	<i>Canopy Choice at the jumper's discretion</i>															

WING LOADING ACCORDING TO MINIMUM CANOPY SIZE RECOMMENDATIONS

		Exit Weight (kg)															
		45	50	55	59	64	68	73	77	82	86	91	95	100	105	109	114
JUMPS	0-25	0,53	0,58	0,63	0,68	0,74	0,79	0,80	0,85	0,90	0,86	0,91	0,95	1,00	0,96	0,92	0,89
	26-50	0,59	0,65	0,71	0,76	0,82	0,79	0,84	0,89	0,90	1,00	1,05	1,05	1,10	1,05	1,00	0,96
	51-100	0,59	0,65	0,80	0,76	0,82	0,88	0,94	1,00	1,06	1,00	1,05	1,11	1,10	1,15	1,09	1,04
	101-200	0,67	0,73	0,80	0,76	0,82	0,88	0,94	1,00	1,06	1,12	1,18	1,24	1,16	1,15	1,20	1,14
	201-300	0,67	0,73	0,89	0,87	0,93	1,00	1,07	1,13	1,06	1,12	1,18	1,24	1,16	1,21	1,26	1,25
	301-400	0,74	0,81	0,89	0,87	0,93	1,00	1,19	1,13	1,20	1,27	1,18	1,24	1,29	1,21	1,26	1,32
	401-500	0,74	0,81	1,00	0,96	1,04	1,11	1,19	1,26	1,20	1,27	1,33	1,24	1,29	1,35	1,26	1,32
	501-750	0,83	0,92	1,00	0,96	1,04	1,11	1,19	1,26	1,33	1,41	1,33	1,40	1,29	1,35	1,41	1,47
	750-1000	0,93	0,92	1,00	1,08	1,04	1,11	1,19	1,26	1,33	1,41	1,48	1,40	1,47	1,35	1,41	1,47
	>1000	<i>Canopy Choice at the jumper's discretion</i>															